

IsoStore Tips for Using Our Dispenser

- 1:** Start by fastening the enclosed ½" metal nozzle to the end cap.
- 2:** Prime the dispenser before using by fully loading and dispensing the Compound twice.
- 3:** Use the thumb plate lock over the thumb release to simplify pulling back the "T" bar to load.
- 4:** Twist the Adjust-a-Stroke mechanism above the handle if you want to adjust the thrust. The "EZ" facing forwards means it will be easier to dispense, but you will squeeze the handle more times (slower to dispense). The "S" facing forward means it will be harder to dispense, but you will squeeze the handle fewer times (faster to dispense).
- 5:** When not in use, fully dispense remaining Compound into the pail and keep the nozzle submerged in water. The Compound will not cure if submerged in water.
- 6:** To avoid loading air pockets, the nozzle and end cap should be fully submerged into the Compound. If you hear air pulling into the barrel, then dispense the Compound and try again.
- 7:** Clean after each use and coat the inner barrel with WD-40 after each cleaning. Disassemble by removing the end cap and unscrewing the barrel. The rest should remain assembled.
- 8:** If the gun will not load, then soak the plunger in warm water and keep pulling back until the dispenser is able to load. This is a quality dispenser that will last several projects if maintained.

Any questions? Call us at 877-866-6473 or email us at info@isostore.com.